




IX

INTELLIGENT ACTUATOR

Horizontal Articulated Robot – IX Series
Tabletop Type, Arm Length 500/600/700/800
IX-NNN50□□/60□□/70□□/80□□

Operation Manual Sixth Edition




IAI America, Inc.

Note on Supply of Brake Power (+24 V) for X-SEL-PX/QX Controllers

If you are using an X-SEL-PX/QX controller, you must supply brake power to the controller, in addition to connecting the brake power cable from the SCARA robot.

Supply the brake power (+24 V) to the controller as shown below.



Please Read Before Use

Thank you for purchasing an IAI product.

This operation manual explains the handling methods, structure and maintenance of this product, among others, providing the information you need to know to use the product safely.

Before using the product, be sure to read this manual and fully understand the contents explained herein to ensure safe use of the product.

The CD or DVD that comes with the product contains operation manuals for IAI products.

When using the product, refer to the necessary portions of the applicable operation manual by printing them out or displaying them on a PC.

After reading the operation manual, keep it in a convenient place so that whoever is handling this product can reference it quickly when necessary.

[Important]

- The product cannot be operated in any way unless expressly specified in this operation manual. IAI shall assume no responsibility for the outcome of any operation not specified herein.
- Information contained in this operation manual is subject to change without notice for the purpose of product improvement.
- This operation manual is original.
- If you have any question or comment regarding the content of this manual, please contact the IAI sales office near you.
- Unauthorized use or reproduction of this operation manual, whether in whole or in part, is strictly prohibited.



CE Marking

If a compliance with the CE Marking is required, please follow Overseas Standards Compliance Manual (ME0287) that is provided separately.

IX

**INTELLIGENT
ACTUATOR**



Table of Contents

Safety Guide	1
Caution in Handling	8
1. Names of Robot Parts	9
1.1 Names of Parts	9
1.2 Labels	10
1.3 Label Positions	11
2. Transportation and Handling	12
2.1 Handling of the Carton	12
2.2 Packing Condition of the Robot	12
2.3 Handling of Individual Components	13
2.4 Checking after Unpacking	13
2.5 Transporting the Robot	14
3. Installation Environment and Storage Environment	15
3.1 Installation Environment	15
3.2 Installation Platform	15
3.3 Storage Environment	15
4. How to Install	17
4.1 Installation Posture	17
4.2 Installing the Robot	18
4.3 Connecting the Controller	19
4.4 Checking after Installation	21
5. Precautions for Use	22
5.1 Reference Acceleration/Deceleration Settings	22
5.2 Tools	24
5.3 Carrying Load	25
5.4 User Wiring and Piping	26
6. Inspection/Maintenance	28
6.1 Inspection/Maintenance	28
6.2 Battery Replacement	30
6.3 Absolute Reset Procedure	33
7. Specifications	50
7.1 Specification Table	50
7.2 External Dimensions	58
7.3 Robot Operation Area	62
7.4 Wiring Diagram	64
7.5 230V Circuit Components	70

8. Warranty	71
8.1 Warranty Period	71
8.2 Scope of Warranty	71
8.3 Honoring the Warranty	71
8.4 Limited Liability	71
8.5 Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications	72
8.6 Other Items Excluded from Warranty	72
Change History	73

Safety Guide

“Safety Guide” has been written to use the machine safely and so prevent personal injury or property damage beforehand. Make sure to read it before the operation of this product.

Safety Precautions for Our Products

The common safety precautions for the use of any of our robots in each operation.

No.	Operation Description	Description
1	Model Selection	<ul style="list-style-type: none"> ● This product has not been planned and designed for the application where high level of safety is required, so the guarantee of the protection of human life is impossible. Accordingly, do not use it in any of the following applications. <ol style="list-style-type: none"> 1) Medical equipment used to maintain, control or otherwise affect human life or physical health. 2) Mechanisms and machinery designed for the purpose of moving or transporting people (For vehicle, railway facility or air navigation facility) 3) Important safety parts of machinery (Safety device, etc.) ● Do not use the product outside the specifications. Failure to do so may considerably shorten the life of the product. ● Do not use it in any of the following environments. <ol style="list-style-type: none"> 1) Location where there is any inflammable gas, inflammable object or explosive 2) Place with potential exposure to radiation 3) Location with the ambient temperature or relative humidity exceeding the specification range 4) Location where radiant heat is added from direct sunlight or other large heat source 5) Location where condensation occurs due to abrupt temperature changes 6) Location where there is any corrosive gas (sulfuric acid or hydrochloric acid) 7) Location exposed to significant amount of dust, salt or iron powder 8) Location subject to direct vibration or impact ● For an actuator used in vertical orientation, select a model which is equipped with a brake. If selecting a model with no brake, the moving part may drop when the power is turned OFF and may cause an accident such as an injury or damage on the work piece.

No.	Operation Description	Description
2	Transportation	<ul style="list-style-type: none"> ● When carrying a heavy object, do the work with two or more persons or utilize equipment such as crane. ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● When in transportation, consider well about the positions to hold, weight and weight balance and pay special attention to the carried object so it would not get hit or dropped. ● Transport it using an appropriate transportation measure. The actuators available for transportation with a crane have eyebolts attached or there are tapped holes to attach bolts. Follow the instructions in the instruction manual for each model. ● Do not step or sit on the package. ● Do not put any heavy thing that can deform the package, on it. ● When using a crane capable of 1t or more of weight, have an operator who has qualifications for crane operation and sling work. ● When using a crane or equivalent equipments, make sure not to hang a load that weighs more than the equipment's capability limit. ● Use a hook that is suitable for the load. Consider the safety factor of the hook in such factors as shear strength. ● Do not get on the load that is hung on a crane. ● Do not leave a load hung up with a crane. ● Do not stand under the load that is hung up with a crane.
3	Storage and Preservation	<ul style="list-style-type: none"> ● The storage and preservation environment conforms to the installation environment. However, especially give consideration to the prevention of condensation. ● Store the products with a consideration not to fall them over or drop due to an act of God such as earthquake.
4	Installation and Start	<p>(1) Installation of Robot Main Body and Controller, etc.</p> <ul style="list-style-type: none"> ● Make sure to securely hold and fix the product (including the work part). A fall, drop or abnormal motion of the product may cause a damage or injury. Also, be equipped for a fall-over or drop due to an act of God such as earthquake. ● Do not get on or put anything on the product. Failure to do so may cause an accidental fall, injury or damage to the product due to a drop of anything, malfunction of the product, performance degradation, or shortening of its life. ● When using the product in any of the places specified below, provide a sufficient shield. <ol style="list-style-type: none"> 1) Location where electric noise is generated 2) Location where high electrical or magnetic field is present 3) Location with the mains or power lines passing nearby 4) Location where the product may come in contact with water, oil or chemical droplets

No.	Operation Description	Description
4	Installation and Start	<p>(2) Cable Wiring</p> <ul style="list-style-type: none"> ● Use our company's genuine cables for connecting between the actuator and controller, and for the teaching tool. ● Do not scratch on the cable. Do not bend it forcibly. Do not pull it. Do not coil it around. Do not insert it. Do not put any heavy thing on it. Failure to do so may cause a fire, electric shock or malfunction due to leakage or continuity error. ● Perform the wiring for the product, after turning OFF the power to the unit, so that there is no wiring error. ● When the direct current power (+24V) is connected, take the great care of the directions of positive and negative poles. If the connection direction is not correct, it might cause a fire, product breakdown or malfunction. ● Connect the cable connector securely so that there is no disconnection or looseness. Failure to do so may cause a fire, electric shock or malfunction of the product. ● Never cut and/or reconnect the cables supplied with the product for the purpose of extending or shortening the cable length. Failure to do so may cause the product to malfunction or cause fire. <p>(3) Grounding</p> <ul style="list-style-type: none"> ● The grounding operation should be performed to prevent an electric shock or electrostatic charge, enhance the noise-resistance ability and control the unnecessary electromagnetic radiation. ● For the ground terminal on the AC power cable of the controller and the grounding plate in the control panel, make sure to use a twisted pair cable with wire thickness 0.5mm² (AWG20 or equivalent) or more for grounding work. For security grounding, it is necessary to select an appropriate wire thickness suitable for the load. Perform wiring that satisfies the specifications (electrical equipment technical standards). ● Perform Class D Grounding (former Class 3 Grounding with ground resistance 100Ω or below).





No.	Operation Description	Description
4	Installation and Start	<p>(4) Safety Measures</p> <ul style="list-style-type: none"> ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● When the product is under operation or in the ready mode, take the safety measures (such as the installation of safety and protection fence) so that nobody can enter the area within the robot's movable range. When the robot under operation is touched, it may result in death or serious injury. ● Make sure to install the emergency stop circuit so that the unit can be stopped immediately in an emergency during the unit operation. ● Take the safety measure not to start up the unit only with the power turning ON. Failure to do so may start up the machine suddenly and cause an injury or damage to the product. ● Take the safety measure not to start up the machine only with the emergency stop cancellation or recovery after the power failure. Failure to do so may result in an electric shock or injury due to unexpected power input. ● When the installation or adjustment operation is to be performed, give clear warnings such as "Under Operation; Do not turn ON the power!" etc. Sudden power input may cause an electric shock or injury. ● Take the measure so that the work part is not dropped in power failure or emergency stop. ● Wear protection gloves, goggle or safety shoes, as necessary, to secure safety. ● Do not insert a finger or object in the openings in the product. Failure to do so may cause an injury, electric shock, damage to the product or fire. ● When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity.
5	Teaching	<ul style="list-style-type: none"> ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● Perform the teaching operation from outside the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the "Stipulations for the Operation" and make sure that all the workers acknowledge and understand them well. ● When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency. ● When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly. ● Place a sign "Under Operation" at the position easy to see. ● When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity. <p>* Safety protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.</p>

No.	Operation Description	Description
6	Trial Operation	<ul style="list-style-type: none"> ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● After the teaching or programming operation, perform the check operation one step by one step and then shift to the automatic operation. ● When the check operation is to be performed inside the safety protection fence, perform the check operation using the previously specified work procedure like the teaching operation. ● Make sure to perform the programmed operation check at the safety speed. Failure to do so may result in an accident due to unexpected motion caused by a program error, etc. ● Do not touch the terminal block or any of the various setting switches in the power ON mode. Failure to do so may result in an electric shock or malfunction.
7	Automatic Operation	<ul style="list-style-type: none"> ● Check before starting the automatic operation or rebooting after operation stop that there is nobody in the safety protection fence. ● Before starting automatic operation, make sure that all peripheral equipment is in an automatic-operation-ready state and there is no alarm indication. ● Make sure to operate automatic operation start from outside of the safety protection fence. ● In the case that there is any abnormal heating, smoke, offensive smell, or abnormal noise in the product, immediately stop the machine and turn OFF the power switch. Failure to do so may result in a fire or damage to the product. ● When a power failure occurs, turn OFF the power switch. Failure to do so may cause an injury or damage to the product, due to a sudden motion of the product in the recovery operation from the power failure.

No.	Operation Description	Description
8	Maintenance and Inspection	<ul style="list-style-type: none"> ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● Perform the work out of the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the “Stipulations for the Operation” and make sure that all the workers acknowledge and understand them well. ● When the work is to be performed inside the safety protection fence, basically turn OFF the power switch. ● When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency. ● When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly. ● Place a sign “Under Operation” at the position easy to see. ● For the grease for the guide or ball screw, use appropriate grease according to the Instruction Manual for each model. ● Do not perform the dielectric strength test. Failure to do so may result in a damage to the product. ● When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity. ● The slider or rod may get misaligned OFF the stop position if the servo is turned OFF. Be careful not to get injured or damaged due to an unnecessary operation. ● Pay attention not to lose the cover or untightened screws, and make sure to put the product back to the original condition after maintenance and inspection works. Use in incomplete condition may cause damage to the product or an injury. <p>* Safety protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.</p>
9	Modification and Dismantle	<ul style="list-style-type: none"> ● Do not modify, disassemble, assemble or use of maintenance parts not specified based at your own discretion.
10	Disposal	<ul style="list-style-type: none"> ● When the product becomes no longer usable or necessary, dispose of it properly as an industrial waste. ● When removing the actuator for disposal, pay attention to drop of components when detaching screws. ● Do not put the product in a fire when disposing of it. The product may burst or generate toxic gases.
11	Other	<ul style="list-style-type: none"> ● Do not come close to the product or the harnesses if you are a person who requires a support of medical devices such as a pacemaker. Doing so may affect the performance of your medical device. ● See Overseas Specifications Compliance Manual to check whether complies if necessary. ● For the handling of actuators and controllers, follow the dedicated instruction manual of each unit to ensure the safety.

Alert Indication

The safety precautions are divided into “Danger”, “Warning”, “Caution” and “Notice” according to the warning level, as follows, and described in the Instruction Manual for each model.


Level	Degree of Danger and Damage	Symbol
Danger	This indicates an imminently hazardous situation which, if the product is not handled correctly, will result in death or serious injury.	 Danger
Warning	This indicates a potentially hazardous situation which, if the product is not handled correctly, could result in death or serious injury.	 Warning
Caution	This indicates a potentially hazardous situation which, if the product is not handled correctly, may result in minor injury or property damage.	 Caution
Notice	This indicates lower possibility for the injury, but should be kept to use this product properly.	 Notice

Caution in Handling

1. Make sure to attach the vertical articulated robot properly by following this operation manual.
Using the product with the vertical articulated robot not being certainly retained or affixed may cause abnormal noise, vibration, malfunction or shorten the product life.

1 Names of Robot Parts

1.1 Names of Parts



1.2 Labels

The following labels are attached on the robot and controller. Be sure to observe the instructions and cautions written on the labels to ensure the correct use of the robot/controller.

Labels on the Robot

Prohibition of entry into the operation area




Warning on handling of the vertical axis




Warning against electric shock



Robot serial number




CE-certified robot (Provided only for CE-certified models)




Labels on the Controller


Caution/warning on handling of the controller




Designation of the connected robot



Controller serial number (Other than CE-certified models)




Controller serial number (CE-certified models)




Danger	Warning	Caution
<ul style="list-style-type: none"> ● Failure to observe the cautionary information provided on the labels may result in serious injury or damage to the robot. 		

1.3 Label Positions

Label Positions on the Robot



Label Positions on the Controller



2 Transportation and Handling


2.1 Handling of the Carton

Each robot is packed with a controller prior to shipment.

When transporting the carton containing the robot and controller, observe the following items and be careful not to drop the carton or apply impact due to forcible contact:

- If the carton is heavy, one operator should not attempt to carry it alone.
- Place the carton on a level surface if it is to be left there for a while.
- Do not climb upon the carton.
- Do not place on the carton any heavy object that may cause the carton to deform, or an article whose shape allows a load to be concentrated at one point.

2.2 Packing Condition of the Robot



Warning



Caution

- The robot and controller are very heavy. When transporting the carton containing the robot and controller, handle it with extra care so as not to drop the carton or apply impact due to forcible contact, as it may cause injury or damage to the robot or controller.
- Serious injury may result if the carton is dropped onto a person during transportation.
- Never stand below the carton as it is hoisted.
- Use a carrier device with sufficient loading capacity.
- If a machine or method is used that requires specified skills, it must be operated/performed by a person having the proper qualifications.

2.3 Handling of Individual Components

The robot and controller are supplied as a set.

Your robot cannot be used with the controller supplied with another robot.

When handling multiple robots, be careful not to lose their correct pairings with the controllers.

The robot will not stand on its own after being unloaded from the carton pallet.

Hold it by hand, or place a cushioning material on the floor and place the robot on its side upon the cushion.

2.4 Checking after Unpacking

After unpacking the carton, check the condition of the robot and other items contained in the carton.

Standard parts

Robot	1
Controller	1
Operation manual for robot	1
Operation manual for controller	1

Accessories

Eyebolt	2
D-sub connector	1
Hood set (for D-sub connector)	1
Caution label	2
Positioning label	1
PIO flat cable	1

Optional parts

PC software (type: IA-101-X-MW)	
CD-ROM	2
PC connection cable	1
Hand-held emergency-stop switch	1
Operation manual for PC software	1

Absolute reset adjustment jig

Type: JG-1 (IX-NNN50□□, IX-NNN60□□)
 JG-3 (IX-NNN70□□, IX-NNN80□□)

Positioning jig for axes 1 and 2	1
Positioning jig for axis 4	1

Absolute data backup battery (AB-3)



Caution



Note


- Always operate the robot using the controller supplied with the robot in the same carton. Using another controller may result in an unexpected operation, damaged motor or other problem.
- After unpacking, be sure to confirm the condition of the robot and other items contained in the carton. Should you find a damaged or missing part, please contact IAI immediately.



2.5 Transporting the Robot

When transporting the robot, affix the arms using the supplied arm fixing plate. Additionally, wrap the cables around the base and secure them with gummed tape or other means.

Use a dolly, forklift, crane or other appropriate equipment for transportation. When transporting the robot, move it slowly by maintaining balance and safeguarding against vibration or impact.

When a crane is used, install the supplied eyebolts on the robot for the pass-through of ropes. Install the eyebolts following removal of the top cover.



 Danger	 Warning
<ul style="list-style-type: none"> ● If the arms and cables remain free, the arms may turn unexpectedly and pinch a hand, or a person may be tripped by the trailing cables. ● Do not attempt to carry the robot by hand, as it may injure the back. Additionally, an injury may result if the robot is dropped onto the feet. ● Serious injury may result if a person is caught under a fallen robot during transportation. ● Never stand below the robot as it is hoisted. ● Use a hoist and ropes that can comfortably support the weight of the robot. ● If a machine or method is used that requires specified skills, it must be operated/performed by a person having the proper qualifications. 	

3 Installation Environment and Storage Environment

3.1 Installation Environment

Install the robot in an environment that satisfies the following conditions:

- Away from direct sunlight
- Not subject to radiated heat from a high-capacity energy source such as a heat-treating furnace
- Ambient temperature: 0°C to 40°C
- Humidity: 85% or less (non-condensing)
- Not exposed to corrosive or flammable gases
- Not subject to impact or vibration
- Not exposed to a significant amount of electromagnetic waves, ultraviolet rays or radiation
- Sufficient space is available to ensure safety in teaching and maintenance/inspection operations

Generally, the robot must be installed where the operator need not wear protective gear in order to work.

3.2 Installation Platform

The platform on which to install the robot receives a significant reactive force. Be certain the platform has sufficient rigidity to withstand the anticipated force.

- The surface on which the robot is fixed must have a thickness of 25 mm or more.
The levelness of the robot installation surface must be at least ± 0.05 mm.
- Drill tapped holes, as indicated below, into the installation surface of the platform.

Type	Tap size	Remarks
IX-NNN50□□/60□□	M10	Effective thread: 10 mm or longer for steel (20 mm or longer for aluminum)
IX-NNN70□□/80□□	M12	Effective thread: 12 mm or longer for steel (24mm or longer for aluminum)

- The platform must have sufficient rigidity to withstand not only the weight of the robot but also the dynamic moment of inertia that is generated when the robot is operated at maximum speed.
- Secure the platform to the floor or other rigid structure in a manner that prevents any movement due to operation of the robot.
- The installation platform must allow the robot to be mounted on a level surface.

3.3 Storage Environment

The storage environment conforms to the installation environment. If the robot is to be stored for a prolonged period of time, be sure the robot will not be exposed to dew condensation.

Unless otherwise specified, desiccant is not placed in the carton when shipped. If the robot is to be kept in an environment subject to condensation, provide preventive measures from over the carton or directly to the robot after unpacking.

The maximum storage temperature is 60°C for a short storage period. If the robot is to be stored for more than a month, the ambient temperature should not exceed 50°C.



Danger



Warning




- Failure to provide a proper environment for installation and storage may shorten the service life of the robot, reduce its operation accuracy, or cause a malfunction or failure.
- Never use the robot in a flammable atmosphere. The robot may explode or ignite.

4 How to Install

Shown below is how to install SCARA Robot.

4.1 Installation Posture

○ : Available × : Not available

Horizontally Oriented Mount	Wall-Mount	Ceiling-Mount
		
○	×	×


4.2 Installing the Robot

Install the robot on a level surface.

Secure the robot using hex bolts and washers.

Type	Bolt size	Tightening torque
IX-NNN50□□/60□□	M10	60 N·m
IX-NNN70□□/80□□	M12	104 N·m

For the hex bolts, use high-tension bolts with an ISO rating of 10.9 or higher.



Warning



Caution


- Always insert a washer below each bolt. Without a washer, the bolt-bearing surface may sink.
- Tighten the hex bolts securely to the correct torque. Improperly tightened bolts may reduce the accuracy of robot operation, and in the worst case cause the robot to overturn.

4.3 Connecting the Controller

The controller connection cables are attached on the robot (standard cable: 5 m, to air-tube joint: 150 mm).

Pay attention to the following items when connecting the controller:

- Connect to the robot of the serial number specified on the robot designation label provided on the front panel of the controller.



- Connect the cables securely after confirming that they are free from damage or bent connector pins.
- Connect each cable by aligning the indication on the marking tube on the cable with the indication on the controller panel.
- When installing the PG connector (D-sub connector), ensure correct orientation of the connector.
- The brake power circuit is provided on the primary side (high-voltage side). Therefore, provide a dedicated 24 VDC power supply for the brake. Do not attempt to share the secondary circuit power sources such as I/O power source.

The brake power to be supplied to Horizontal Articulated Robot should be 24V DC $\pm 10\%$ and the voltage source capacity 20W.

The brake power to be supplied to the XSEL-PX/QX controller should be 24V DC $\pm 10\%$ and the voltage source capacity 9W.

(Note) It is necessary to increase the voltage source capacity of the brake power source if brake actuators are to be connected to the 5th and 6th axes of the XSEL-PX/QX controller.


[Refer to the section of the voltage source capacity and heat generation in the controller operation manual.]

Refer to the operation manuals for the controller and PC software for the procedures to connect the I/O cable, controller power cable, PC connection cable, etc.



Warning

- Be sure to connect to the robot of the serial number specified on the front panel of the controller. The controller will not operate properly if any other robot is connected. Failure to observe this warning may cause the robot to malfunction, resulting in a serious accident.
- Before connecting or disconnecting a cable, always turn off the power to the controller. Connecting/disconnecting a cable with the power supplied to the controller may cause the robot to malfunction, resulting in a serious accident.
- Installing the connectors into the wrong sockets may cause the robot to malfunction. Be sure to check the designation on the cable with that on the controller panel before plugging in any connector.
- If the connectors are not inserted securely, the robot may malfunction and generate the risk of danger. Be sure to affix each connector with the supplied screws.



Warning

- Before connecting or disconnecting a cable, always turn off the power to the controller. Connecting/disconnecting a cable with the power supplied to the controller may cause the robot to malfunction, resulting in a serious accident.
- Installing the connectors into the wrong sockets may cause the robot to malfunction. Be sure to check the designation on the cable with that on the controller panel before plugging in any connector.
- If the connectors are not inserted securely, the robot may malfunction and generate the risk of danger. Be sure to affix each connector with the supplied screws.

4.4 Checking after Installation

Once the robot has been installed, check the following items:

- Visually check the robot, controller and cables for dents and other abnormalities.
- Confirm that the cables are connected properly and that the connectors are inserted securely.



Warning


- Failure to perform these checks may result in a malfunctioning robot or a damaged controller or robot.

5 Precautions for Use

5.1 Reference Acceleration/Deceleration Settings

Use the robot based on appropriate acceleration/deceleration settings by referring to the following graph:



(1) PTP operation (Set using the SEL language commands ACCS and DCLS.)



Caution

- To operate the robot at the maximum acceleration, provide a stopping period of three seconds or more after each acceleration/deceleration.
- When arm 1 is operated over 125 degrees or more, use the reference range for the continuous operation setting as the reference range of the maximum setting. The continuous operation setting value should be one-third the appropriate maximum value thus set.
- Start from the appropriate reference range for the continuous operation setting, and then gradually raise the value for the purpose of adjustment.
- If an overload error occurs, lower the acceleration setting as appropriate or provide an appropriate stopping time following each acceleration/deceleration.
- Depending on the position of the vertical axis, the robot may generate vibration when axis 1, axis 2 or the rotational axis turns. If vibration occurs, lower the acceleration as appropriate.
- To move the robot horizontally at high speed, keep the vertical axis as close as possible to the top position. If the vertical axis is operated at the bottom position, the ball screw spline shaft will bend and the vertical axis will be disabled.
- Be careful that the moment of inertia of axis 4 does not exceed the permissible value. (Refer to 5.3, "Carrying Load.")
- The carrying load indicates a load above the rotational center of axis 4.
- Operate the robot by using an appropriate acceleration coefficient as determined by the mass of the tip. Failure to do so may cause the drive part to wear prematurely or may result in damage or vibration.

(2) CP operation (Set using the SEL language commands ACC and DCL.)



⚠ Caution

- To operate the robot at the maximum acceleration, provide a stopping period of three seconds or more after each acceleration/deceleration.
- Start from the appropriate reference range for the continuous operation setting, and then gradually raise the value for the purpose of adjustment.
- If an overload error occurs, lower the acceleration setting as appropriate or provide an appropriate stopping time following each acceleration/deceleration.
- Depending on the position of the vertical axis, the robot may generate vibration when axis 1, axis 2 or the rotational axis turns. If vibration occurs, lower the acceleration as appropriate.
- To move the robot horizontally at high speed, keep the vertical axis as close as possible to the top position. If the vertical axis is operated at the bottom position, the ball screw spline shaft will bend and the vertical axis will be disabled.
- Be careful that the moment of inertia of axis 4 does not exceed the permissible value. (Refer to 5.3, "Carrying Load.")
- The carrying load indicates a load above the rotational center of axis 4.
- Operate the robot by using an appropriate acceleration coefficient as determined by the mass of the tip. Failure to do so may cause the drive part to wear prematurely or may result in damage or vibration.

5.2 Tools

The tool mounting part must have sufficient strength and rigidity, along with adequate fastening power to prevent positional shift.

It is recommended that a tool be installed over a split ring, span ring or other appropriate part. A sample configuration of tool installation is given below.


The diameter of each tool must not exceed 100 mm. A tool larger than this dimension will interfere with the robot within the robot's range of movement.

If the tool diameter exceeds 100 mm or the tool contacts any peripheral equipment, decrease the soft limits to reduce the operation range.

Also keep the inertial moments of the tool and load within the allowable values. (Refer to 5.3, "Carrying Load.")

Adjust the position (direction) of axis 4 (rotational axis) using the D-cut surface at the tip of axis 4.

If the position in rotating direction is to be determined using the D-cut surface with a setscrew, use a setscrew with resin/brass pad or screw in a setting piece made of soft material. (Avoid affixing the tool by bolting it on the D-cut surface. It will damage the D-cut positioning surface.)



Warning



Caution

- Turn off the power to the controller and robot before installing a tool.
- If the tool mounting part does not have sufficient strength, it may break while the robot is operating and cause the tool to detach and fly off.
- If the tool diameter exceeds 100 mm, the tool will contact the robot within its range of movement and cause damage to the tool, work and/or robot.
- Avoid attachment of the tool at the D-cut surface via thread fastening. Doing so may damage the D-cut positioning surface.

5.3 Carrying Load


Load capacity

Type	Rated load capacity	Maximum load capacity
IX-NNN50□□/60□□	2 kg	10 kg
IX-NNN70□□/80□□	5 kg	20 kg

Load's permissible moment of inertia

Type	Permissible moment of inertia	Remarks
IX-NNN50□□/60□□	0.06 kg·m ²	Both rated and maximum
IX-NNN70□□/80□□	0.10 kg·m ²	

Load offset (from the center of axis 4 (rotational axis))
50 mm or less




Caution

- Set appropriate acceleration/deceleration according to the mass of the tip and moment of inertia. Failure to do so may cause the drive part to wear prematurely or may result in damage or vibration.
- If vibration occurs, lower the acceleration/deceleration as appropriate.
- If the load gets offset, the robot becomes more likely to cause vibration. Design the tools so that the load's center of gravity aligns with the center of axis 4.
- Do not move the robot horizontally with axis 3 (vertical axis) extended. It may cause the vertical axis to bend and disable the axis. To move the robot horizontally with axis 3 extended, adjust the speed and acceleration/deceleration as appropriate.

5.4 User Wiring and Piping

The robot comes with standard cables and tubes that the user can use in a desired wiring/piping configuration.



User connector specifications

Rated voltage	3.0 V
Permissible current	1.1 A
Conductor size and number of wires	AWG 26 (0.15 mm ²), 25 wires
Other	Twisted-pair cable (1 to 24), shielded


Piping specifications

Normal service pressure	0.8 MPa
Dimensions (outer diameter x inner diameter) and number of tubes	φ 4 mm x φ 2.5 mm, 2 pieces
	φ 6 mm x φ 4 mm, 2 pieces
Working medium	Air


ALM (indicator) specifications

Rated voltage	24 VDC
Rated current	12 mA
Illumination color	Red LED

Shape of Y-terminal



Spacer for user part installation



External force applied to the spacers must not exceed 30 N in the axial direction or 2 N·m in the rotating direction (for each spacer).

6 Inspection/Maintenance

6.1 Inspection/Maintenance

Your horizontal articulated robot must be inspected daily and on a regular basis to ensure safe, efficient operation. Perform the necessary inspections after confirming the maintenance/inspection items required for your IAI robot, as defined in this section.

Do not perform any inspection, adjustment or repair of the robot or controller, replacement of robot/controller part or any other operation not described in this operation manual. The following items must be adjusted at our factory. Do not disassemble the following components or cut cables at the user site:

- Disassembly of servo motor
- Disassembly of ball speed reducer
- Disassembly of ball-screw spline
- Disassembly of bearing
- Disassembly of harmonic speed reducer
- Disassembly of brake
- Cutting of cable

IAI will not be responsible for any malfunction or damage resulting from the conduct of any operation cited above.

Depending on the periodic inspection item, the controller power may have to remain on or off. In either case, take proper measures to make sure other operators cannot operate the power.



Warning

- Performing inspection or maintenance without fully understanding the details of work may result in a serious accident.
- If inspections are neglected, the drive part may wear prematurely or the robot may malfunction unexpectedly.

6.1.1 Daily Inspection

Check the following items daily before and after operating the robot.
Observe the precautions for work near the robot and for inspection/maintenance/adjustment operations when carrying out each check.

Check location	Description
Safety cage	<ul style="list-style-type: none"> • Correct the deformation or positional shift of the cage. • Confirm that the interlock mechanism is operating properly.
Robot	<ul style="list-style-type: none"> • Check the robot mounting bolts for looseness. • Check the exterior for abnormality, loose covers, flaws, dents, etc. (If the robot has flaws or other abnormalities, please contact IAI.) • Check for abnormal move, vibration or noise.
Cables	<ul style="list-style-type: none"> • Check the cables for flaws. • Check the cable mounting parts for looseness.
Emergency-stop switch	<ul style="list-style-type: none"> • Confirm that the emergency-stop switch functions properly.

6.1.2 Six-Month Inspection

Check the following items on the robot every six months.
Observe the precautions for work near the robot and for inspection/maintenance/adjustment operations when carrying out each check.

Check location	Description
Robot	Check the arm mounting sections for looseness. (If any of the arm mounting sections is loose, tighten the fastening parts securely.)
Ball-screw spline	<ul style="list-style-type: none"> • Check the ball screw and spline for looseness. • Wipe off old grease using a waste cloth, etc., and add new grease. (Standard specification: Multemp LRL No. 3 by Kyodo Yushi or equivalent)
Connectors	Check the connectors for looseness.

If the robot has flaws or other abnormalities, please contact IAI.



Caution

- In case the grease got into your eye, immediately go to see the doctor to get an appropriate care.
- After finishing the grease supply work, wash your hands carefully with water and soap to rinse the grease off.

6.1.3 Yearly Inspection

Check the following items on the robot every year.

Observe the precautions for work near the robot and for inspection/maintenance/adjustment operations when carrying out each check.

Check location	Description
Harmonic reduction gears, joint bearings	Check arm 1 or 2 for looseness in the rotating direction or axial direction. (Contact IAI if an abnormality is found.)
Ball-screw spline	Check the vertical axis for looseness. (Contact IAI if an abnormality is found.)



Warning

- Performing inspection or maintenance without fully understanding the details of work may result in a serious accident.
- If inspections are neglected, the drive part may wear prematurely or the robot may malfunction unexpectedly.
- Display a “Work in Progress” sign so that other operators will not operate the controller, operation panel, etc.

6.2 Battery Replacement

6.2.1 Preparation

The following items are required when replacing the batteries:

- Phillips screwdriver
- New dedicated batteries for IX: AB-3 (4 pieces)

Before replacing the batteries, turn off the power to the controller, control panel and other relevant units.



Warning



Caution



- Performing inspection or maintenance without fully understanding the details of work may result in a serious accident.
- Display a “Work in Progress” sign so that other operators will not operate the controller, operation panel, etc.
- Use dedicated batteries for IX. Batteries for the old model (IH) cannot be used.

6.2.2 Battery Replacement Procedure

- (1) Remove the countersunk head screws (1) (six pieces) and detach the cover (base).
- (2) Remove the batteries from the battery holder.
- (3) Remove the battery connectors and connect new batteries.



- After removing the old batteries, quickly connect new batteries (roughly within 5 minutes x number of batteries).
- If new batteries are not connected for a longer period, the rotation data will be lost and an absolute reset will become necessary.
- Replace batteries one axis at a time. If the batteries for all axes are replaced at once, the work may not be completed within the specified time.

- (4) Install the batteries into the battery holder.



Battery holder

- (5) Affix the cover (base) using the countersunk head screws (1) (six pieces) (tightening torque: 0.74 N·m).



Do not tighten the screws to the specified torque in one go. First tighten the screws to the position shown to the left, and while pushing the cover in the direction of the arrow tighten the screws on both sides evenly to ensure tight sealing.



Caution

- When installing the cover (base), be careful not to pinch the cables inside.

- (2) Connect the cables for the robot, controller and PC, so the robot can be operated from the PC.
Before commencing the work, always confirm that the emergency-stop switch is functioning properly.
- (3) Back up the parameters.
Be sure to back up the parameters before performing an absolute reset.
- (4) Start the absolute reset menu.
- (5) Perform an absolute reset.
- (6) Perform a software reset.




Warning

- Performing inspection or maintenance without fully understanding the details of work may result in a serious accident.
- Display a “Work in Progress” sign so that other operators will not operate the controller, operation panel, etc.
- Perform an absolute reset after backing up the parameters.


6.3.2 Starting the Absolute Reset Menu

(1) Open the absolute reset window from the PC software.




(2) The absolute reset window opens.

- One of three absolute reset screens—for arm 1, arm 2 and rotational axis + vertical axis—is displayed when a corresponding tab is clicked.




6.3.3 Absolute Reset Procedure for Arm 1 or 2


(1) Click the “Encoder Rotation Data Reset1” button.




(2) Click the “Reset Controller Error” button.




(3) Click the “Servo ON” button.



(4) Jog the arm to near the reference position (see reference position drawing in step 7), and click the “Jog end” button.



(5) Click the “Servo-OFF” button.




- (6) Press the emergency-stop switch.
- (7) When performing an absolute reset of arm 1, set an adjustment jig (pin) on arm 1 to fix the arm in the reference position. In this case, arm 2 may be moved. When performing an absolute reset of arm 2, set an adjustment jig (pin) on arm 2 to fix the arm in the reference position. In this case, arm 1 may be moved.
 - Set the jig after confirming that the emergency-stop switch is pressed.
 - Set the jig after adjusting the arm to the reference position, using the positioning mark label as a guide.
 - Arm 1 has a cover (not arm 2), which is fixed with setscrews. Remove the setscrews and detach the cover before setting the jig.
 - It is recommended that an adjustment jig be used to perform an absolute reset. With arm 1 or 2, however, rotation data can be reset as long as a positioning accuracy of “center of positioning mark label ± 1 graduation” is ensured.




Arm 1



Arm 2



Positioning mark label for arm 1



Reference position drawing


Adjust arm 1 or 2 to a position within ± 1 graduation of the center.




Warning

- Always press the emergency-stop switch before setting an adjustment jig. Failure to do so may cause the robot to malfunction and result in a serious accident.

(8) Click the “OK” button.




(9) Click the “Encoder Rotation Data Reset2” button.



- (10) Remove the adjustment jig.
 - If you are working on arm 1, install the cover and secure it with the setscrews
- (11) Release the emergency-stop switch.
- (12) Click the “OK” button.

- An arrow is shown next to the “Home pos. automatic update” button. Do not set this item. (In particular, be sure this item is not set when performing an absolute reset without using a jig).
- If the home position is updated automatically when a reset is performed without using an adjustment jig, the home position will become offset.
- If the home position has been updated by mistake, perform a software reset without writing to flash ROM. (This achieves the same condition where the home position is not updated automatically.)
- Always click the “OK” button after removing the jig and releasing the emergency-stop switch.



- (13) Click “X” in the top right-hand corner to exit the absolute reset window.
 - Once the absolute reset is complete, be sure to reset the controller. From “Control (C)” in the menu bar, select “Software Reset (R).” A software reset will be performed. (Refer to 6.3.5.)




Caution


- Be careful not to perform a reset using an incorrect sequence, since it may cause the arm position to become offset.
- Update the home position only when a mechanical change (relating to a joint) has been made to the system, such as after an arm has been replaced.

6.3.4 Absolute Reset Procedure for the Rotational Axis + Vertical Axis


(1) Click “Encoder Rotation Data Reset1” button.



(2) Click the “Reset Controller Error” button.




(3) Click the “Servo ON” button.




(4) Click the “Temp. Standard posture standby” button.


- The vertical axis returns to its home position. Exercise caution so as not to be injured by the axis during movement.



(5) Jog the rotational axis to the reference position (see reference position drawing in step 8), and click the “Jog end” button.





(6) Click the “Servo-OFF” button.



(7) Press the emergency-stop switch.

(8) Affix the rotational axis at the reference position by setting the plate and pin of the adjustment jig as illustrated below.


- Set the jig after confirming that the emergency-stop switch is pressed.
- Set the jig after adjusting the rotational axis to the reference position, using the positioning mark label as a guide.
- The top face of the stopper should roughly align with the bottom face of arm 2.




Warning

- Always press the emergency-stop switch before setting an adjustment jig. Failure to do so may cause the robot to malfunction and result in a serious accident.
- Pay attention to the orientation of the D-cut surface of the plate jig.


(9) Click the "OK" button.



(10) Click the "Encoder Rotation Data Reset2" button.




(11) Click the “Home pos. automatic update” button.




(12) Remove the adjustment jig.

(13) Release the emergency-stop switch.

(14) Click the “OK” button.




(15) Click the “Servo ON” button.




(16) Click the “Standard posture standby” button.


- The vertical axis returns to its home position. Exercise caution so as not to be injured by the axis during movement.



(17) Click the “Servo-OFF” button.




(18) Click the “Encoder Rotation Data Reset3” button.




(19) Click the “Home pos. automatic update” button, and then click “X” in the top right-hand corner to exit the absolute reset window.

- Once the absolute reset is complete, be sure to write the flash ROM and reset the controller.



- (20) If an absolute reset was performed on both the rotational axis and vertical axis or if the home position was updated automatically based on arm 1 or 2 by mistake, closing the absolute reset window will open the following screen. Click the “No” button.
- Click “Yes” only if you have released a mechanical connection such as replacing an arm or belt.
 - Click “No” if you have replaced a cable.
 - When all steps are finished, be sure to perform a “software reset.”



- (21) Perform a software reset.
To perform a software reset, select “Software Reset (R)” from “Control (C)” in the menu bar. (Refer to 6.3.5.)

7 Specifications

7.1 Specification Table

IX-NNN50□□ (Arm Length 500, Standard Specification)

Item		Specifications	
Type		IX-NNN50□□-□□L-T1	
Degree of freedom		Four degrees of freedom	
Overall arm length	mm	500	
Arm 1 length		250	
Arm 2 length		250	
Drive method	Axis 1 (arm 1)	AC servo motor + Speed reducer	
	Axis 2 (arm 2)	AC servo motor + Speed reducer	
	Axis 3 (vertical axis)	AC servo motor with brake + Belt + Ball-screw spline	
	Axis 4 (rotational axis)	AC servo motor with brake + Speed reducer + Belt + Spline	
Motor capacity	Axis 1 (arm 1)	W	400
	Axis 2 (arm 2)		200
	Axis 3 (vertical axis)		200
	Axis 4 (rotational axis)		100
Movement range	Axis 1 (arm 1)	degree	±120
	Axis 2 (arm 2)		±145
	Axis 3 (vertical axis) (*1)	mm	200 (Optional: 300)
	Axis 4 (rotational axis)	degree	±360
Maximum operating speed (*2)	Axis 1 + Axis 2 (maximum composite speed)	mm/sec	6283
	Axis 3 (vertical axis)		1393
	Axis 4 (rotational axis)	degree/sec	1200
Positioning repeatability accuracy (*3)	Axis 1 + Axis 2	mm	±0.010
	Axis 3 (vertical axis)		±0.010
	Axis 4 (rotational axis)	degree	±0.005
Standard cycle time (*4)		sec	0.44
Load capacity	Rated	kg	2
	Maximum		10
Push-in thrust of axis 3 (vertical axis)	Dynamic (*8)	N (kgf)	152 (15.5)
	Static (*9)		108 (11.0)
Permissible load on axis 4	Permissible moment of inertia (*5)	kg·m ²	0.06
	Permissible torque	N·m (kgf·cm)	3.3 (33.6)
Permissible tool diameter (*6)		mm	φ 100
Origin detection	Absolute		
User wiring	D-sub 25-pin connector with 25-core AWG26 shielded cable (socket)		
Alarm indicator (*7)	One small, red LED indicator (rated voltage: 24 V)		
User piping	Two air tubes (outer diameter: φ 6, inner diameter: φ 4) (normal service pressure: 0.8 MPa) Two air tubes (outer diameter: φ 4, inner diameter: φ 2.5) (normal service pressure: 0.8 MPa)		

Item		Specifications
Operating environment	Ambient temperature/humidity	Temperature: 0 to 40°C, humidity: 20 to 85%RH or less (non-condensing)
	Altitude	1,000 or less
Noise		73
Robot weight		29.5
Brake power source for main unit		24V DC $\pm 10\%$ 20W
Controller	Power supply	230 V 50/60 Hz 8 A
	Allowable supply voltage fluctuation	% ± 10
	Overvoltage category (IEC60664-1)	Category III
	Pollution degree (IEC60664-1)	Pollution degree 3

*1 To move the robot horizontally at high speed, perform teaching so that the vertical axis stays as close to the top position as possible. (Fig. 1)

To operate the robot with its vertical axis at the bottom position, the speed and acceleration must be reduced as appropriate. (Fig. 2)

*2 Assuming PTP instruction operation.

*3 Measured at a constant ambient temperature of 20°C.

*4 Measured when the robot is operated at the maximum speed, carrying a rated load of 2 kg.

Time of reciprocating operation over a vertical travel of 25 mm and horizontal travel of 300 mm (rough positioning)

Note: Continuous operation cannot be performed at the maximum speed.



*5 The permissible moment of inertia converted to a value at the rotational center of axis 4. The offset from the rotational center of axis 4 to the tool's center of gravity is assumed to be 50 mm or less. (Fig. 3)


If the tool's center of gravity is further away from the rotational center of axis 4, the speed and acceleration must be reduced as appropriate.

*6 If the tool exceeds the permissible diameter, it will contact the robot inside the robot's range of movement. (Fig. 4)


*7 To enable the alarm LED indicator, the user must provide a circuit that supplies 24 VDC to the LED terminal in the user connector in response to the controller I/O output signal, etc.

*8 A force of up to three times the dynamic push-in thrust may be applied at any given moment.


*9 The static thrust refers to thrust generated within the robot's range of operation based on a PAPR command (approach distance/speed settings in push motion operation).




(Fig. 1)



(Fig. 2)



(Fig. 3)



(Fig. 4)

Reference design standards: Annex I to Machine Directives, EN292-1, EN292-2, EN1050, EN60204-1, EN775

IX-NNN60□□ (Arm Length 600, Standard Specification)

Item		Specifications	
Type		IX-NNN60□□-□□L-T1	
Degree of freedom		Four degrees of freedom	
Overall arm length	mm	600	
Arm 1 length		350	
Arm 2 length		250	
Drive method	Axis 1 (arm 1)		AC servo motor + Speed reducer
	Axis 2 (arm 2)		AC servo motor + Speed reducer
	Axis 3 (vertical axis)		AC servo motor with brake + Belt + Ball-screw spline
	Axis 4 (rotational axis)		AC servo motor with brake + Speed reducer + Belt + Spline
Motor capacity	Axis 1 (arm 1)		400
	Axis 2 (arm 2)		200
	Axis 3 (vertical axis)		200
	Axis 4 (rotational axis)		100
Movement range	Axis 1 (arm 1)		±120
	Axis 2 (arm 2)		±145
	Axis 3 (vertical axis) (*1)		200 (Optional: 300)
	Axis 4 (rotational axis)		±360
Maximum operating speed (*2)	Axis 1 + Axis 2 (maximum composite speed)		7121
	Axis 3 (vertical axis)		1393
	Axis 4 (rotational axis)		1200
Positioning repeatability accuracy (*3)	Axis 1 + Axis 2		±0.010
	Axis 3 (vertical axis)		±0.010
	Axis 4 (rotational axis)		±0.005
Standard cycle time (*4)		sec	0.52
Load capacity	Rated		2
	Maximum		10
Push-in thrust of axis 3 (vertical axis)	Dynamic (*8)		152 (15.5)
	Static (*9)		108 (11.0)
Permissible load on axis 4	Permissible moment of inertia (*5)		0.06
	Permissible torque		3.3 (33.6)
Permissible tool diameter (*6)		mm	φ 100
Origin detection		Absolute	
User wiring		D-sub 25-pin connector with 25-core AWG26 shielded cable (socket)	
Alarm indicator (*7)		One small, red LED indicator (rated voltage: 24 V)	
User piping		Two air tubes (outer diameter: φ 6, inner diameter: φ 4) (normal service pressure: 0.8 MPa) Two air tubes (outer diameter: φ 4, inner diameter: φ 2.5) (normal service pressure: 0.8 MPa)	

Item		Specifications	
Operating environment	Ambient temperature/humidity		Temperature: 0 to 40°C, humidity: 20 to 85%RH or less (non-condensing)
	Altitude	m	
Noise		dB	73
Robot weight		kg	30.5
Brake power source for main unit		W	24V DC $\pm 10\%$ 20W
Controller	Power supply		230 V 50/60 Hz 8 A
	Allowable supply voltage fluctuation	%	± 10
	Overvoltage category (IEC60664-1)		Category III
	Pollution degree (IEC60664-1)		Pollution degree 3

*1 To move the robot horizontally at high speed, perform teaching so that the vertical axis stays as close to the top position as possible. (Fig. 1)

To operate the robot with its vertical axis at the bottom position, the speed and acceleration must be reduced as appropriate. (Fig. 2)


*2 Assuming PTP instruction operation.

*3 Measured at a constant ambient temperature of 20°C.

*4 Measured when the robot is operated at the maximum speed, carrying a rated load of 2 kg.

Time of reciprocating operation over a vertical travel of 25 mm and horizontal travel of 300 mm (rough positioning)

Note: Continuous operation cannot be performed at the maximum speed.



*5 The permissible moment of inertia converted to a value at the rotational center of axis 4. The offset from the rotational center of axis 4 to the tool's center of gravity is assumed to be 50 mm or less. (Fig. 3)


If the tool's center of gravity is further away from the rotational center of axis 4, the speed and acceleration must be reduced as appropriate.

*6 If the tool exceeds the permissible diameter, it will contact the robot inside the robot's range of movement. (Fig. 4)


*7 To enable the alarm LED indicator, the user must provide a circuit that supplies 24 VDC to the LED terminal in the user connector in response to the controller I/O output signal, etc.

*8 A force of up to three times the dynamic push-in thrust may be applied at any given moment.


*9 The static thrust refers to thrust generated within the robot's range of operation based on a PAPR command (approach distance/speed settings in push motion operation).




(Fig. 1)



(Fig. 2)



(Fig. 3)



(Fig. 4)

Reference design standards: Annex I to Machine Directives, EN292-1, EN292-2, EN1050, EN60204-1, EN775

IX-NNN70□□ (Arm Length 700, Standard Specification)

Item		Specifications	
Type		IX-NNN70□□-□□L-T1	
Degree of freedom		Four degrees of freedom	
Overall arm length	mm	700	
Arm 1 length		350	
Arm 2 length		350	
Drive method	Axis 1 (arm 1)	AC servo motor + Speed reducer	
	Axis 2 (arm 2)	AC servo motor + Speed reducer	
	Axis 3 (vertical axis)	AC servo motor with brake + Belt + Ball-screw spline	
	Axis 4 (rotational axis)	AC servo motor with brake + Speed reducer + Belt + Spline	
Motor capacity	Axis 1 (arm 1)	W	750
	Axis 2 (arm 2)		400
	Axis 3 (vertical axis)		400
	Axis 4 (rotational axis)		200
Movement range	Axis 1 (arm 1)	degree	±125
	Axis 2 (arm 2)		±145
	Axis 3 (vertical axis) (*1)	mm	200 (Optional: 400)
	Axis 4 (rotational axis)	degree	±360
Maximum operating speed (*2)	Axis 1 + Axis 2 (maximum composite speed)	mm/sec	6597
	Axis 3 (vertical axis)		1583
	Axis 4 (rotational axis)	degree/sec	1200
Positioning repeatability accuracy (*3)	Axis 1 + Axis 2	mm	±0.015
	Axis 3 (vertical axis)		±0.010
	Axis 4 (rotational axis)	degree	±0.005
Standard cycle time (*4)		sec	0.50
Load capacity	Rated	kg	5
	Maximum		20
Push-in thrust of axis 3 (vertical axis)	Dynamic (*8)	N (kgf)	265 (27.0)
	Static (*9)		188 (19.1)
Permissible load on axis 4	Permissible moment of inertia (*5)	kg·m ²	0.1
	Permissible torque	N·m (kgf·cm)	6.7 (68.3)
Permissible tool diameter (*6)		mm	φ 100
Origin detection	Absolute		
User wiring	D-sub 25-pin connector with 25-core AWG26 shielded cable (socket)		
Alarm indicator (*7)	One small, red LED indicator (rated voltage: 24 V)		
User piping	Two air tubes (outer diameter: φ 6, inner diameter: φ 4) (normal service pressure: 0.8 MPa) Two air tubes (outer diameter: φ 4, inner diameter: φ 2.5) (normal service pressure: 0.8 MPa)		

Item		Specifications
Operating environment	Ambient temperature/humidity	Temperature: 0 to 40°C, humidity: 20 to 85%RH or less (non-condensing)
	Altitude	1,000 or less m
Noise		74 dB
Robot weight		58 kg
Brake power source for main unit		24V DC \pm 10% 20W
Controller	Power supply	230 V 50/60 Hz 15 A
	Allowable supply voltage fluctuation	% \pm 10
	Overvoltage category (IEC60664-1)	Category III
	Pollution degree (IEC60664-1)	Pollution degree 3

*1 To move the robot horizontally at high speed, perform teaching so that the vertical axis stays as close to the top position as possible. (Fig. 1)

To operate the robot with its vertical axis at the bottom position, the speed and acceleration must be reduced as appropriate. (Fig. 2)

*2 Assuming PTP instruction operation.

*3 Measured at a constant ambient temperature of 20°C.

*4 Measured when the robot is operated at the maximum speed, carrying a rated load of 5 kg. Time of reciprocating operation over a vertical travel of 25 mm and horizontal travel of 300 mm (rough positioning)

Note: Continuous operation cannot be performed at the maximum speed.



*5 The permissible moment of inertia converted to a value at the rotational center of axis 4. The offset from the rotational center of axis 4 to the tool's center of gravity is assumed to be 50 mm or less. (Fig. 3)


If the tool's center of gravity is further away from the rotational center of axis 4, the speed and acceleration must be reduced as appropriate.

*6 If the tool exceeds the permissible diameter, it will contact the robot inside the robot's range of movement. (Fig. 4)


*7 To enable the alarm LED indicator, the user must provide a circuit that supplies 24 VDC to the LED terminal in the user connector in response to the controller I/O output signal, etc.

*8 A force of up to three times the dynamic push-in thrust may be applied at any given moment.


*9 The static thrust refers to thrust generated within the robot's range of operation based on a PAPR command (approach distance/speed settings in push motion operation).




(Fig. 1)



(Fig. 2)



(Fig. 3)



(Fig. 4)

Reference design standards: Annex I to Machine Directives, EN292-1, EN292-2, EN1050, EN60204-1, EN775

IX-NNN80□□ (Arm Length 800, Standard Specification)

Item			Specifications
Type			IX-NNN80□□-□□L-T1
Degree of freedom			Four degrees of freedom
Overall arm length		mm	800
Arm 1 length			450
Arm 2 length			350
Drive method	Axis 1 (arm 1)		AC servo motor + Speed reducer
	Axis 2 (arm 2)		AC servo motor + Speed reducer
	Axis 3 (vertical axis)		AC servo motor with brake + Belt + Ball-screw spline
	Axis 4 (rotational axis)		AC servo motor with brake + Speed reducer + Belt + Spline
Motor capacity	Axis 1 (arm 1)		750
	Axis 2 (arm 2)		400
	Axis 3 (vertical axis)		400
	Axis 4 (rotational axis)		200
Movement range	Axis 1 (arm 1)		±125
	Axis 2 (arm 2)		±145
	Axis 3 (vertical axis) (*1)		200 (Optional: 400)
	Axis 4 (rotational axis)		±360
Maximum operating speed (*2)	Axis 1 + Axis 2 (maximum composite speed)		7121
	Axis 3 (vertical axis)		1583
	Axis 4 (rotational axis)		1200
Positioning repeatability accuracy (*3)	Axis 1 + Axis 2		±0.015
	Axis 3 (vertical axis)		±0.010
	Axis 4 (rotational axis)		±0.005
Standard cycle time (*4)		sec	0.52
Load capacity	Rated		5
	Maximum		20
Push-in thrust of axis 3 (vertical axis)	Dynamic (*8)		265 (27.0)
	Static (*9)		188 (19.1)
Permissible load on axis 4	Permissible moment of inertia (*5)		0.1
	Permissible torque		6.7 (68.3)
Permissible tool diameter (*6)		mm	φ 100
Origin detection			Absolute
User wiring			D-sub 25-pin connector with 25-core AWG26 shielded cable (socket)
Alarm indicator (*7)			One small, red LED indicator (rated voltage: 24 V)
User piping			Two air tubes (outer diameter: φ 6, inner diameter: φ 4) (normal service pressure: 0.8 MPa) Two air tubes (outer diameter: φ 4, inner diameter: φ 2.5) (normal service pressure: 0.8 MPa)

Item		Specifications	
Operating environment	Ambient temperature/humidity		Temperature: 0 to 40°C, humidity: 20 to 85%RH or less (non-condensing)
	Altitude	m	
Noise		dB	74
Robot weight		kg	60
Brake power source for main unit		W	24V DC $\pm 10\%$ 20W
Controller	Power supply		230 V 50/60 Hz 15 A
	Allowable supply voltage fluctuation	%	± 10
	Overvoltage category (IEC60664-1)		Category III
	Pollution degree (IEC60664-1)		Pollution degree 3

*1 To move the robot horizontally at high speed, perform teaching so that the vertical axis stays as close to the top position as possible. (Fig. 1)

To operate the robot with its vertical axis at the bottom position, the speed and acceleration must be reduced as appropriate. (Fig. 2)


*2 Assuming PTP instruction operation.

*3 Measured at a constant ambient temperature of 20°C.

*4 Measured when the robot is operated at the maximum speed, carrying a rated load of 5 kg.

Time of reciprocating operation over a vertical travel of 25 mm and horizontal travel of 300 mm (rough positioning)

Note: Continuous operation cannot be performed at the maximum speed.



*5 The permissible moment of inertia converted to a value at the rotational center of axis 4. The offset from the rotational center of axis 4 to the tool's center of gravity is assumed to be 50 mm or less. (Fig. 3)


If the tool's center of gravity is further away from the rotational center of axis 4, the speed and acceleration must be reduced as appropriate.

*6 If the tool exceeds the permissible diameter, it will contact the robot inside the robot's range of movement. (Fig. 4)


*7 To enable the alarm LED indicator, the user must provide a circuit that supplies 24 VDC to the LED terminal in the user connector in response to the controller I/O output signal, etc.

*8 A force of up to three times the dynamic push-in thrust may be applied at any given moment.


*9 The static thrust refers to thrust generated within the robot's range of operation based on a PAPER command.




(Fig. 1)



(Fig. 2)



(Fig. 3)




(Fig. 4)

Reference design standards: Annex I to Machine Directives, EN292-1, EN292-2, EN1050, EN60204-1, EN775


7.2 External Dimensions

IX-NNN50□□




*1: The holes for the 2-M4 screws (depth 8) pierce through the thickness of the arm's side wall. If the mounting screws are long, they will contact the internal parts. Exercise due caution in this regard.
 *2: External force applied to the spacers must not exceed 30 N in the axial direction or 2 N·m in the rotating direction (for each spacer).
 *3: The LED operates only when the user provides a circuit that receives controller I/O output signal and supplies 24 VDC to the LED terminal in the user connector.

IX-NNN60□□




7.3 Robot Operation Area

IX-NNN50□□




(Operation prohibited area)

Movement range




Stopper position range

IX-NNN60□□




(Operation prohibited area)

Movement range




Stopper position range


IX-NNN70□□



IX-NNN80□□




7.4 Wiring Diagram



Notes

- (1) The actual layout of board connectors varies from this drawing.
- (2) Since the brake power circuit is provided on the primary side (high-voltage side), a dedicated 24 V power supply is required for this circuit. The 24 V power supply for I/O circuits used on the secondary side (low-voltage side) cannot be shared.
- (3) To operate the alarm LED, the user must provide a circuit that uses the controller I/O output signal.



D-sub connector for user piping
(25 pins, socket)

Alarm LED




Brake release switch for
axis 3, axis 4 (Z, R)

Air joints
Red (Ø6), yellow (Ø6),
black (Ø4), white (Ø4)

Machine Harness Wiring Table






(1) PG cables (inside machine) DWG No. 1069363*

Base end Arm end

Tube symbol	Connector	Signal	Pin No.	Connection	Pin No.	Signal	Connector	Tube symbol	ID No.	Wire
OUT PG2	Mini universal Mate-N-Lock plug housing 172169-1 (Tyco Electronics AMP)	BAT+	1		1	BAT+	Mini universal Mate-N-Lock Socket housing for panel installation 172169-1 (Tyco Electronics AMP)	PG 2	Red	0.3 mm ² shield wire
		BAT-	2		2	BAT-			White	
		SD	3		3	SD			Red	
		-SD	4		4	-SD			White	
		Vcc	5		5	Vcc			Red	
		GND	6		6	GND			White	
		Shield	7		7	Shield			Green	
			8		8					
			9		9					
OUT PG3	Same as above	BAT+	1		1	BAT+	Same as above	PG 3	Red	0.3 mm ² shield wire
		BAT-	2		2	BAT-			White	
		SD	3		3	SD			Red	
		-SD	4		4	-SD			White	
		Vcc	5		5	Vcc			Red	
		GND	6		6	GND			White	
		Shield	7		7	Shield			Green	
			8		8					
			9		9					
OUT PG4	Same as above	BAT+	1		1	BAT+	Same as above	PG 4	Red	0.3 mm ² shield wire
		BAT-	2		2	BAT-			White	
		SD	3		3	SD			Red	
		-SD	4		4	-SD			White	
		Vcc	5		5	Vcc			Red	
		GND	6		6	GND			White	
		Shield				Shield			Green	
			8		8					
			9		9					

(2) M cables (inside machine) DWG No. 1068651*


Base end Arm end

Tube symbol	Connector	Signal	Pin No.	Connection	Pin No.	Signal	Connector	Tube symbol	ID No.	Wire
M 2	Mini universal Mate-N-Lock plug housing 172167-1 (Tyco Electronics AMP)	U	1		1	U	Mini universal Mate-N-Lock Socket housing for panel installation 172159-1 (Tyco Electronics AMP)	U	1	Flexible cable
		V	2		2	V		V	2	
		W	3		3	W		W	3	
		C · G	4		4	C · G		C · G	4	
M 3	Same as above	U	1		1	U	Same as above	U	5	16 × AWG18
		V	2		2	V		V	6	
		W	3		3	W		W	7	
		C · G	4		4	C · G		C · G	8	
M 4	Same as above	U	1		1	U	Same as above	U	9	16 × AWG18
		V	2		2	V		V	10	
		W	3		3	W		W	11	
		C · G	4		4	C · G		C · G	12	
BK 3	Mini universal Mate-N-Lock plug housing 172165-1 (Tyco Electronics AMP)	BK-	1		1	BK-	Mini universal Mate-N-Lock Socket housing for panel installation 172157-1 (Tyco Electronics AMP)	BK-	13	Flexible cable
		BK+	2		2	BK+		BK+	14	
BK 4	Same as above	BK-	1		1	BK-	Same as above	BK-	15	Flexible cable
		BK+	2		2	BK+		BK+	16	

(3) UA, UB cables (outside machine) DWG No. 1069364*

Base end

Arm end

Tube symbol	Connector	Signal	Pin No.	Connection	Pin No.	Signal	Connector	Tube symbol	ID No.	Wire
UA	Double brazed relay plug DF11-14DEP-2C (Hirose Electric)	U 1	1		1	U 1	Double brazed crimp socket DF11-14DEP-2C (Hirose Electric)	UA	Black	
		U 2	2		2	U 2				
		U 3	3		3	U 3				
		U 4	4		4	U 4				
		U 5	5		5	U 5				
		U 6	6		6	U 6				
		U 7	7		7	U 7				
		U 8	8		8	U 8				
		U 9	9		9	U 9				
		U 10	10		10	U 10				
		U 11	11		11	U 11				
		U 12	12		12	U 12				
		U 13	13		13	U 13				
		U 14	14		14	U 14				
UB	Same as above	U 15	1	1	U 15	Same as above	UB	White	0.3 mm ² shield wire	
		U 16	2	2	U 16					
		U 17	3	3	U 17					
		U 18	4	4	U 18					
		U 19	5	5	U 19					
		U 20	6	6	U 20					
		U 21	7	7	U 21					
		U 22	8	8	U 22					
		U 23	9	9	U 23					
		U 24	10	10	U 24					
		U 25	11	11	U 25					
		LED+24V	12	12	—					
		LEDG24V	13	13	—					
		—	14	14	FG					
SW	Mini universal Mate-N-Lock plug housing 172166-1 (Tyco Electronics AMP)	BK 4	1	1	LED+24V	Single brazed crimp socket DF3-2S-2C (Hirose Electric)	LED	White	Red	
		COM	2	2	LEDG24V					
		BK 3	3	1	BK 4					
	Bare terminal (Y type) F0.3-3	FG	—	2	COM	Single brazed crimp socket DF3-3S-2C (Hirose Electric)	BK	Black	Red	
				3	BK 3					

Robot Cable Wiring Table

(1) PG cables (outside machine) DWG No. 1068656*

Robot end				Controller end						
Tube symbol	Connector	Signal	Pin No.	Connection	Pin No.	Signal	Connector	Tube symbol	ID No.	Wire
INPG1 INPG2 INPG3 INPG4	Female crimp connector HIF3BA-10D-2.5 4C (Hirose Electric)	BAT+	1		1	-	Housing KEC-15P (JST)	PG1 PG2 PG3 PG4	-	-
		BAT-	2		2	-			-	
		SD	3		3	-			-	
		-SD	4		4	-			-	
		Vcc	5		5	-			-	
		GND	6		6	-			-	
		BK-	7		7	SD			-	
		BK+	8		8	-SD			-	
		FG	9		9	BAT+			-	
		-	10		10	BAT-			-	
			11		Vcc	-				
			12		GND	-				
			13		BK-	-				
			14		BK+	-				
			15		-	-				
						Connector hood D13A (for 17HE-23150-C) (DDK)				
										4P x AWG26
										Light gray 1 red Light gray 1 black Orange 1 red Orange 1 black White 1 red White 1 black Yellow 1 red Yellow 1 black

(2) M cables (outside machine)

DWG No. 1068655*

Robot end				Controller end						
Tube symbol	Connector	Signal	Pin No.	Connection	Pin No.	Signal	Connector	Tube symbol	ID No.	Wire
M 1	Mini universal Mate-N-Lock socket housing for panel installation172159-1 (Tyco Electronics AMP)	U	1		1	C · G	Reverse plug GIC2.5 4-sTF-7.62 (Phoenix)	M 1	4	
		V	2		2	U			1	
		W	3		3	V			2	
		C · G	4		4	W			3	
M 2	Same as above	U	1		1	C · G	Same as above	M 2	8	
		V	2		2	U			5	
		W	3		3	V			6	
		C · G	4		4	W			7	
M 3	Same as above	U	1		1	C · G	Same as above	M 3	12	
		V	2		2	U			9	
		W	3		3	V			10	
		C · G	4		4	W			11	
M 4	Same as above	U	1		1	C · G	Same as above	M 4	16	
		V	2		2	U			13	
		W	3		3	V			14	
		C · G	4		4	W			15	

(3) UA, UB cables (outside machine) DWG No. 1068657*

Robot end

Controller end

Tube symbol	Connector	Signal	Pin No.	Connection	Pin No.	Signal	Connector	Tube symbol	ID No.	Wire
UA	Double brazed crimp socket DF11-14DS-2C (Hirose Electric)	U 1	1		1	U 1	Bare terminal (Y type) F0.3-3	U1	Orange 1 red	15P x AWG26
		U 2	2		2	U 2	Same as above	U2	Orange 1 black	
		U 3	3		3	U 3	Same as above	U3	Light gray 1 red	
		U 4	4		4	U 4	Same as above	U4	Light gray 1 black	
		U 5	5		5	U 5	Same as above	U5	White 1 red	
		U 6	6		6	U 6	Same as above	U6	White 1 black	
		U 7	7		7	U 7	Same as above	U7	Yellow 1 red	
		U 8	8		8	U 8	Same as above	U8	Yellow 1 black	
		U 9	9		9	U 9	Same as above	U9	Pink 1 red	
		U10	10		10	U10	Same as above	U10	Pink 1 black	
		U11	11		11	U11	Same as above	U11	Orange 2 black	
		U12	12		12	U12	Same as above	U12	Orange 2 black	
		U13	13		13	U13	Same as above	U13	Light gray 2 red	
		U14	14		14	U14	Same as above	U14	Light gray 2 black	
UB	Same as above	U15	1	1	U15	Same as above	U15	White 2 red		
		U16	2	2	U16	Same as above	U16	White 2 black		
		U17	3	3	U17	Same as above	U17	Yellow 2 red		
		U18	4	4	U18	Same as above	U18	Yellow 2 black		
		U19	5	5	U19	Same as above	U19	Pink 2 red		
		U20	6	6	U20	Same as above	U20	Pink 2 black		
		U21	7	7	U21	Same as above	U21	Orange 3 red		
		U22	8	8	U22	Same as above	U22	Orange 3 black		
		U23	9	9	U23	Same as above	U23	Light gray 3 red		
		U24	10	10	U24	Same as above	U24	Light gray 3 black		
		U25	11	11	U25	Same as above	U25	White 3 red		
		LED+24V	12	12	LED+24V	Same as above	LED+24V	White 3 black		
		LEDG24V	13	13	LEDG24V	Same as above	LEDG24V	Yellow 3 red		
		-	14	-	FG	Same as above	FG	Green		

7.5 230V Circuit Components

IX-NNN50□□/60□□

No.	Code name	Model	Manufacturer	Remarks
1	Axis 1 servo motor	TS4609 N2027 E200	Tamagawa Seiki	AC servo motor, □ 60, 400 W, key groove, CE certified
2	Axis 2 servo motor	TS4607 N2027 E200		AC servo motor, □ 60, 200 W, key groove, CE certified
3	Axis 3 servo motor w/ brake	TS4607 N7027 E200		AC servo motor, □ 60, 200 W, w/ brake, round shaft, CE certified
4	Axis 4 servo motor w/ brake	TS4606 N7027 E200		AC servo motor, □ 60, 100 W, key groove, CE certified
5	M cable (inside robot)		IAI	Wire: 300 V, 105°C (rated), AWG18 (0.84 mm ²), flexible cable, UL VW-1, c-UL FT-1
6	M cable (outside robot)		IAI	Wire: 300 V, 80°C (rated), AWG18 (0.89 mm ²), oil-resistant cable, UL VW-1, c-UL FT-1

IX-NNN70□□/80□□

No.	Code name	Model	Manufacturer	Remarks
1	Axis 1 servo motor	TS4614 N2027 E200	Tamagawa Seiki	AC servo motor, □ 80, 750 W, key groove, CE certified
2	Axis 2 servo motor	TS4609 N2027 E200		AC servo motor, □ 60, 400 W, key groove, CE certified
3	Axis 3 servo motor w/ brake	TS4609 N7027 E200		AC servo motor, □ 60, 400 W, w/ brake, round shaft, CE certified
4	Axis 4 servo motor w/ brake	TS4607 N2027 E200		AC servo motor, □ 60, 200 W, key groove, CE certified
5	M cable (inside robot)		IAI	Wire: 300 V, 105°C (rated), AWG18 (0.84 mm ²), flexible cable, UL VW-1, c-UL FT-1
6	M cable (outside robot)		IAI	Wire: 300 V, 80°C (rated), AWG18 (0.89 mm ²), oil-resistant cable, UL VW-1, c-UL FT-1

8. Warranty

8.1 Warranty Period

One of the following periods, whichever is shorter:

- 18 months after shipment from our company
- 12 months after delivery to the specified location
- 2,500 hours of operation

8.2 Scope of Warranty

Our products are covered by warranty when all of the following conditions are met. Faulty products covered by warranty will be replaced or repaired free of charge:

- (1) The breakdown or problem in question pertains to our product as delivered by us or our authorized dealer.
- (2) The breakdown or problem in question occurred during the warranty period.
- (3) The breakdown or problem in question occurred while the product was in use for an appropriate purpose under the conditions and environment of use specified in the operation manual and catalog.
- (4) The breakdown of problem in question was caused by a specification defect or problem, or by a quality issue with our product.

Note that breakdowns due to any of the following reasons are excluded from the scope of warranty:

- [1] Anything other than our product
- [2] Modification or repair performed by a party other than us (unless we have approved such modification or repair)
- [3] Anything that could not be easily predicted with the level of science and technology available at the time of shipment from our company
- [4] A natural disaster, man-made disaster, incident or accident for which we are not liable
- [5] Natural fading of paint or other symptoms of aging
- [6] Wear, depletion or other expected result of use
- [7] Operation noise, vibration or other subjective sensation not affecting function or maintenance

Note that the warranty only covers our product as delivered and that any secondary loss arising from a breakdown of our product is excluded from the scope of warranty.

8.3 Honoring the Warranty

As a rule, the product must be brought to us for repair under warranty.

8.4 Limited Liability

- (1) We shall assume no liability for any special damage, consequential loss or passive loss such as a loss of expected profit arising from or in connection with our product.
- (2) We shall not be liable for any program or control method created by the customer to operate our product or for the result of such program or control method.

8.5 Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications

- (1) If our product is combined with another product or any system, device, etc., used by the customer, the customer must first check the applicable standards, regulations and/or rules. The customer is also responsible for confirming that such combination with our product conforms to the applicable standards, etc. In such a case we will not be liable for the conformance of our product with the applicable standards, etc.
- (2) Our product is for general industrial use. It is not intended or designed for the applications specified below, which require a high level of safety. Accordingly, as a rule our product cannot be used in these applications. Contact us if you must use our product for any of these applications:
 - [1] Medical equipment pertaining to maintenance or management of human life or health
 - [2] A mechanism or mechanical equipment intended to move or transport people (such as a vehicle, railway facility or aviation facility)
 - [3] Important safety parts of mechanical equipment (such as safety devices)
 - [4] Equipment used to handle cultural assets, art or other irreplaceable items
- (3) Contact us at the earliest opportunity if our product is to be used in any condition or environment that differs from what is specified in the catalog or operation manual.

8.6 Other Items Excluded from Warranty

The price of the product delivered to you does not include expenses associated with programming, the dispatch of engineers, etc. Accordingly, a separate fee will be charged in the following cases even during the warranty period:

- [1] Guidance for installation/adjustment and witnessing of test operation
- [2] Maintenance and inspection
- [3] Technical guidance and education on operating/wiring methods, etc.
- [4] Technical guidance and education on programming and other items related to programs



IAI Corporation

Head Office: 577-1 Obane Shimizu-KU Shizuoka City Shizuoka 424-0103, Japan
TEL +81-54-364-5105 FAX +81-54-364-2589
website: www.iai-robot.co.jp/

Technical Support available in USA, Europe and China

IAI America, Inc.

Head Office: 2690 W. 237th Street, Torrance, CA 90505
TEL (310) 891-6015 FAX (310) 891-0815
Chicago Office: 1261 Hamilton Parkway, Itasca, IL 60143
TEL (630) 467-9900 FAX (630) 467-9912
Atlanta Office: 1220 Kennestone Circle, Suite 108, Marietta, GA 30066
TEL (678) 354-9470 FAX (678) 354-9471
website: www.intelligentactuator.com

IAI Industrieroboter GmbH

Ober der Röth 4, D-65824 Schwalbach am Taunus, Germany
TEL 06196-88950 FAX 06196-889524

IAI (Shanghai) Co., Ltd.

SHANGHAI JIAHUA BUSINESS CENTER A8-303, 808, Hongqiao Rd. Shanghai 200030, China
TEL 021-6448-4753 FAX 021-6448-3992
website: www.iai-robot.com